



(Any contents related to 4G/MMS are for 4G model only.)

V1.0

Pls scan QR codes below to download APP for remote control functions of 4G model.



For IOS APP

For Android APP

Contents

1. Quick Start

- 1.1 What in the Box?
- 1.2 Whole view and details of camera

Figure 1: Front View

Figure 2: Bottom View

- Figure 3: Internal, Side and Back View
- 1.3 How to get the camera ready?

2. Camera Setup

- 2.1 How to setup camera?
- 2.2 How to setup 4G?
- 2.3 Camera default setting in Red Letter

3. Introduction

- 3.1 Power Supply
- 3.2 SD Card Selection
- 3.3 USB Connection
- 3.4 Attention
- 3.5 Key Features

4. Operation List

- 4.1 Video/ Photo Playback
- 4.2 Delete
- 4.3 Format of SD Card
- 4.4 Auto Power Off
- 4.5 Operation Menu

5. Trouble Shooting

- 5.1 Photos do not capture subjects of Interest
- 5.2 Camera stops taking images or won't take image
- 5.3 Night vision flash range doesn't meet expectation
- 6. Specification
- 7. Warranty

1. Quick Set 1.1 What's in the Box?

- 2. Trail camera x 1
- 3. Instruction manual x 1
- 4. USB cable ×1
- 5. Mounting strap ×1
- 6. Antenna ×2 (4G Model Only)








Figure 2: Bottom View

SIM CARD Golden Part Faces Front Housing Side





1.3 How to get the camera ready?

1.Inserting Batteries

Open camera housing by unclipping the clip which is located on the right side. Insert 12 AA Batteries as electrodes marked in the battery case.

Note: 12 AA Alkaline or Ni-MH rechargeable batteries are recommended





2. Inserting SD Card

Insert SD card in the card slot which is located on the bottom of the camera.

Note: Camera can take 1-32 GB SD Card



3. Mounting Antenna & Inserting SIM Card (for 4G Only)

a. Mounting Antenna

Remove the two-yellow cap on top of the camera. Take both antennas and screw to the antenna connection.





b. Inserting SIM Card

Insert SIM Card into the SIM slot located on the left side of camera and push it downed to clip it in place.



2 Camera Setup 2.1How to setup camera?

1. Configure Camera Setting

Switch to "SETUP" screen will light up, press "M" key you will enter the menu to view and change settings. Please press arrow keys to navigation and "OK" key confirm setting.

Note: Please switch to "ON" to enable camera to work after setups.

Please refer to page 8 below for default setting in Red Letter

2.2 How to setup 4G?

1. How to connect the camera to Network (For 4G Only)

Different from none cellular models the 4G models has a signal "Searching" process when you switch the power key to setup.


If it comes with a signal bar and no other pop-up it means the network is automatically connected, by then you only need to fill in phone number and email in "SEND TO" to receive photos upon motion trigger.

If it comes with a pop-up "SIM AUTO MATCH FAILED", please go to "SIM AUTO MATCH" under"4G" select "MANUAL" and fill in local operator APN details in "MANUAL SETUP", the camera will connect to network to send photos.

Note: This camera can send photos to 4 phones & 4 emails. It's set to send photos to phone via MMS and photos/videos to email via SMTP (data). If you prefer more personalized way of sending, please configure in menu accordingly.

2. Power on the Camera

Switch to "ON"; camera is ready to work upon motion triggers (screen will not light up upon "ON"). You can mount it up.



GPS OFF/ON

2.3Camera Default setting in Red Letter

3 Introduction 3.1Power Supply

A. Batteries

Camera runs on 12 AA size batteries (9-12V power supply to ensure camera well performance of all function); can work with alkaline and high-quality NiMH rechargeable batteries. Please also choose the battery type you're using in the menu option "BATTERY TPYE" to reach longer operation time.

Batteries should be inserted with correct electrode position as marked in battery case. Upside down batteries electrodes may cause device malfunction. Also, we strongly recommend changing the batteries when the power icon on camera or photo stamp is empty.

NOTE: DON'T MIX BATTERIES TYPES!!!!! DIFFERENT BATTERIES TO USE IN CAMERA MAY CAUSE PERMANENT DAMAGE WHICH ALSO VIOLATES WARRANTY POLICY!

Due to different settings, objects activities within camera detection zone, different brands and quality of batteries and using environment, etc; we're not able to list out exact number of photos and videos that camera can achieve. So, given table below only show approximate number of photos or videos camera, can take with 12 AA alkaline batteries, better performance can be given by 12 AA rechargeable NiMH batteries.

| | | 12AA | Alkaline Batteries | | |
|------------|------------|--------------|--------------------|----------|--------------|
| Photos sho | ot per day | Working time | Video clips shot p | er day | Working time |
| | | I I | IR LEDs On | | |
| Max.Range | 100 pics | 81 days | | | |
| Balanced | 100 pics | 76 days | 10secs video clips | 10 clips | 75 days |
| Min. Blur | 100 pics | 70 days | | | |
| | | | IR LEDs Off | | |
| Photo | 100 pics | 113 days | 10secs video clips | 10 clips | 228 days |

B. Solar Panel

To bring user to better experience, our engineers deigned this camera to be able to work most standard 12V/2A Lithium Battery build-in solar panels. However, as rechargeable AA NiMH batteries need higher voltage for charging that solar panel can't charge the batteries in using in camera batteries case.

C. Power Adaptor – Security Surveillance Purpose

This camera can also be powered by external 12V/12A DC adaptor. Recommend removing the AA size batteries when power adaptor is used. Electrical power is recommended for security purpose.

3.2SD Card Selection

Using a memory card is required to operate the camera. When the camera is "ON" and no memory card is used, the screen display "NO CARD". The SD slot of the camera has a 32GB memory capacity. **Before inserting or removing the memory card, the camera must be turned "off", failing to do so may cause loss of or damage the pictures/ videos already recorded from the memory card.** When SD card is full, the viewing screen show "MEMORY FULL". The following data shows on approximate quantity of photos or videos which can be recorded by the camera depending on the memory card capacity.

Chart below will show you the approximate capacity of different size SD cards. Please check to see which size card can fit your needs bests.

| SD Size Capacity | 1GB | 2 GB | 4 GB | 8 GB | 16 GB | 32 GB |
|---------------------|----------|----------|---------------|----------|----------|----------|
| | | Р | hoto (picture | s) | | |
| 5MP | 869 | 1631 | 3585 | 7492 | 15307 | 30936 |
| 8 MP | 556 | 1041 | 2294 | 4798 | 9794 | 19795 |
| 12 MP | 391 | 733 | 1613 | 3371 | 6887 | 13919 |
| | | | Video (hours) | | | |
| 640x480 | 00:05:27 | 00:10:13 | 00:22:28 | 00:46:57 | 01:35:56 | 03:13:52 |
| HD | 00:03:56 | 00:07:23 | 00:16:13 | 00:33:53 | 01:09:14 | 02:19:56 |
| FHD | 00:02:04 | 00:03:53 | 00:08:31 | 00:17:48 | 00:36:20 | 01:13:21 |

3.3USB Connection

When camera is connected via USB cable screen display "MSDC", press "MENU" once, "MSDC" turns to "PC CAM", camera now can be used as a PC camera. Press "MENU" again, camera exist PC camera mode.

3.4Attention

- 1. Insert the SD memory card correctly, camera does not support SD card hot swap (insertion)
- 2. Please use high quality Alkaline AA batteries to prevent battery cells from corrosion of leaked acid.
- 3. Use right adaptor (12V/2A) of this camera to supply power and do not invert the electrode when put in batteries.
- 4. In test mode, camera will automatically power off in 3 mins if there is no keypad touching.
- 5. Don't interrupt supply during firmware upgrade, please deliver it back to factory if the device doesn't work after upgrading.
- 6. Do not frequently insert or out SD card and batteries or plug in and out the adaptor when the camera is ON.
- 7. Do not have any floating objects, in the motion detection zone of camera, such as leaves, strings or ribbons to avoid mistaking photos or videos.
- 8. Do not keep camera next to hot irrelevant object, air conditioner exhaust vent.
- Camera is a 52° FOV lens and 57° pcs 60° IR LEDs. To ensure these 57 pcs LEDs can give enough flash that high quality AA batteries must be applied according to deliver enough amperage to power the illuminator consistently in dark environment.
- 10. Programmed date/time can be saved in camera for 12 hours as long was camera was powered 1 hour above.

3.5 Key Feature

- 1. 0.4 seconds trigger speed
- 2. Regular Lens models: 52°FOV lens; 65°PIR angles
- 3. Wide Lens models: 100°FOV lens; 100°PIR angles
- 4. 12MP/1080P @30FPS
- 5. Programmable 5/8/12 megapixel high-quality resolution.
- 6. 57 PCS invisible IR LEDs offer 20 meters (65 fee) real night vision distance.
- 7. Crystal clear day & night photo/video quality.
- 8. 1 photo burst per second to get full moving track of objects.
- 9. Support multiple functions adjustable PIR sensitivity multi-[shot (1-5 photos pre-trigger), programmable delay between motions, time lapse, timer, stamp of (camera ID, date/time, temperature, moon phase) on every single photo.
- 10. Available operation temperature: -25° to 60°
- 11.Built-in 2.0" TFT colour screen.
- 12.With MMS/4G/SMTP/FTP function camera can transmit photo to 1-4 pre-set mobile phones 1-4 email and FTP account per trigger.
- 13.SMS to realize various remote configurations.
- 14.SMS to enable camera to shoot a photo and send back instantly.
- 15.Optional small size (640*480) large size (1920*1440) and 5/8/12MP email/ FTP photos
- 16.App available in IOS & ANDROID App Store

4. Operation list

4.1 Video/Photo Playback

Turn "Power switch" to SETUP position to entre test mode press arrow button "↑" to enter Playback; press "←" and " →" for selecting "OK" to play photo/video.

- 1) Press button " ↑ " again to exit
- 2) In Playback Mode, press "MENU" button to delete files or format SD card; press "MENU" again to exit.
- 4.2 Delete

a. Delete one: delete selected photo/video; Press "OK" to choose, press " \uparrow " and " \downarrow " for selection. "YES" to confirm "NO" to exit to previous page.

b. Delete All

4.3 Format of SD Card

a. No

4.4 Auto Power Off

In test mode, camera will automatically power off in 3 mins if there is no keypad touching. Please manually turn "ON" it as if you want to do some further configuration.

Note: Camera stay in "TEST MODE" if camera is in "MENU" configuration page.

4.5 Operation Menu

Test mode, Press "Menu" once to enter camera setting menu; to navigate setting interface by pressing " \leftarrow ", " \uparrow ", " \rightarrow ", or " \downarrow ", press "OK" for selection, "Menu" to exit to previous page, and "Menu" to switch alpha/ digits/ symbols.

Note: For some settings, user needs to press "Menu" to save & exit the configuration after pressing "OK" to confirm; (Cam ID, Deley, Time Lapse, Timer, Password)

| Cam | PIR | 4G | Other | Cam | PIR | 4G | Other |
|--------------|-----|----|-------|--------------|-----|----|-------|
| Cam ID OI | | | OFF | Multi-s | hot | | 1P |
| Cam Mode | | | 0 | Video Size | | | HD |
| Flash LED | | | All | Video Length | | | 05 |
| Image Size | | 5M | | | | | |
| Night Mode | | | -Å- | | | | |
| MENU Exit OK | | | Set | MENU E | xit | OK | Set |
| | | | | | | | |

| Cam | Cam | | | | |
|----------|---|--|--|--|--|
| Settings | Programmable Options | | | | |
| Cam ID | Select "ON", press "OK", to set 12 digits/ alphabets for each camera. Such function can help user to identify photos are from where and which camera. | | | | |
| Cam Mode | Photo, PIC+VIDEO, Video | | | | |
| | Photo: camera shoots photos only based on configured Multi-shot & Image Size; | | | | |
| | 2) "PIC+VIDEO", camera shoots photo(s) first, then video upon same trigger event based on Video Length/Size and Multi-shot/ Image Size user | | | | |

| | configured; |
|--------------|--|
| | 3) Video: camera shoots videos only based on configured Video Length/Size; |
| Flash LED | All/Part |
| | |
| | All: all 57pcs IR LEDs will work in dark environment; |
| | Part: Bottom 30pcs IR LEDs will be turned off. |
| Image Size | 5MP (2560*1920), 8MP (3264*2448), 12MP (4032*3024) |
| Night Mode | a) Min. Blur: Short exposure time to minimize motion blur for better image quality; shortened IR flash range; |
| | b) Max. Range: Longer exposure time to extend IR flash range for better night vision; lower image quality; |
| | c) Balanced: combination of above 2 options; |
| Multi-shot | Programmable 1~5 photos per trigger |
| Video On | |
| Video Size | 1280*720, 640*480, 1920*1080, |
| Video length | 05~59 Secs |

| | 4G | Other | Cam | PIR | 4G | Othe |
|-------------|----|-------|--------|-----|----|------|
| PIR Switch | | ON | Timer2 | | | OF |
| Sensitivity | | | | | | |
| Delay | | OFF | 1 | | | |
| Time Lapse | | OFF | - 4 | | | |
| Timer 1 | | OFF | | | | |
| MENU Exit | OK | Set | MENU | vit | OK | Set |

| PIR | |
|----------|----------------------|
| Settings | Programmable Options |

| PIR Switch | OFF/ON |
|-------------|---|
| | Note: |
| | a) With PIR Switch off, camera will not be able to take photo/ video per motion; |
| | b) With PIR Switch on, camera is able to take photos/ videos per motion even when Time Lapse is ON. |
| Sensitivity | High, Middle, Low |
| | Higher sensitivity is 1) more sensitive to movements by smaller subjects; 2) longer detection distance; 3) easier for sensor to detect difference between body heat and outdoor temperature; 4) easier to trigger camera to record. In high temperature environment, body heat of subjects and environment temperature is hard to tell by camera, suggest setting High. |
| Delay | Select "ON", press "OK", to set a time interval between photos or videos upon motion. This option can avoid camera taking too many photos or videos. |
| | Example: Camera will wait 1 minute between photo/video recordings with motion if pre-set time interval is 00:01:00 |
| | Configurable delay time: 00:00:05~23:59:59. |
| | Note: Only Time Lapse works if Time Lapse and Delay are turned on. |
| Time Lapse | Select "ON", press "OK", to set the interval; camera will shoot pics or video clips automatically upon the interval user set. Object motion can still trigger the camera to take photos/ videos if PIR Switch is ON. |
| | Configurable interval: 00:00:05~23:59:59. |
| | Note: Only Time Lapse works if Time Lapse and Delay are turned on. |
| Timer1 | Select "ON", press "OK", to set the beginning time and end time |
| | (hour/minute); camera will only work during the time period user set. |
| | i.e.: 15:00 – 18:00; camera only works during 15:00 – 18:00 |
| Timer2 | Select "ON", press "OK", to set the beginning time and end time |
| | (hour/minute); camera will only work during the time period user set. |

| i.e.: 15:00 | – 18:00; camera c | only works durin | g 15:00 – 18:00 | | |
|------------------|-------------------|------------------|-----------------|------------|--|
| Cam PIR 46 Other | Cam PIR | 46 Other | Cam PIR | 46 Other | |
| SIM Auto Match | Daily Report | OFF | Send To | | |
| Manual Setup | SIM PIN | ON | Transfer mode | | |
| MMS OFF | | | SMTP/FTP Pic O | ptions | |
| SMTP D | | | Max Num/Day | Unlimited | |
| FTP ON | | | SMS Ctrl | By Trigger | |
| MENU Exit OK Set | MENU Exit | OK Set | MENU Exit | OK Set | |

Per this menu, main functions are marked in grey; details below each function are explanation of this function.

| 4G | | | | | | | |
|------------------|---|--|--|--|--|--|--|
| SIM Auto Match | SIM Auto Match | | | | | | |
| 1) Camera will a | utomatically enter MMS & 4G setups when the SIM card is inserted; | | | | | | |
| , | natch failed, pls enter setups manually" pops up on screen, pls switch "SIM to "Manual" mode, then enter MMS & 4G setups in "Manual Setup"; | | | | | | |
| Manual Setup | | | | | | | |
| · · · | below manually in "Manual" mode if your local operator can't be atched by camera itself.) | | | | | | |
| | Pls contact your operator for URL/ APN/ IP/ Port (Username & Password if required); and enter these info manually. | | | | | | |
| | (We'll add the needed operator info into "SIM Auto Match" list whenever we're informed with the detail effective information.) | | | | | | |
| MMS | Note: 1. With MMS setups added, camera can send photos to preset phones/ email. If MMS is with wrong information entered, then phones/ email accounts will not be able to receive photos from camera. | | | | | | |
| | 2. Email box receive photos from camera via SMTP only when SMTP is ON. | | | | | | |
| | Enter your local operator's 4G APN, and corresponding Username and Password. | | | | | | |
| 4G | Note: Only with 4G setups added, can SMTP and FTP functions work. | | | | | | |
| | Note: it's not a must to enter Username and Password of APN. But some operators may require this password access to enable 4G function. For details, pls contact your local operator. | | | | | | |

| | | ON/OFF | | | | | |
|------|--|---|--|--|--|--|--|
| MN | IS | You can simply choose to allow pics to be sent to your phone number via MMS by switch ON/ OFF MMS function here. | | | | | |
| | | MMS can only send small size pics to your phone number | | | | | |
| SM | TP | | | | | | |
| | mera comes w counts in "Ser | rith default SMTP setups; you only need to enter receiving email nd to" | | | | | |
| Pls | finish setups | below if you'd like to use your own SMTP server. | | | | | |
| 1) | Enter your ma | ilbox server IP; | | | | | |
| i.e. | : | | | | | | |
| Ho | tmail IP: smtp.li | ve.com; | | | | | |
| Gn | nail IP: smtp.gm | nail.com; | | | | | |
| 2) | Enter your ma | ilbox port; | | | | | |
| Po | rt of most mailb | ox is 25; plz enter your mailbox corresponding port. | | | | | |
| 3) | Enter your ma | ilbox password access. | | | | | |
| | | ly send photos to preset emails; if SMTP is with wrong information entered, t be able to receive photos from camera. | | | | | |
| 2. 1 | MMS stops sen | ding photos to email when SMTP is set to work. | | | | | |
| FT | P | | | | | | |
| 1) | Enter your FT | P server IP; | | | | | |
| | i.e.: | | | | | | |
| | FTP Server IF | : ftp://dianwan2008.gicp.net/ | | | | | |
| | Enter: dianwa | n2008.gicp.net | | | | | |
| | Gmail IP: smt | p.gmail.com; | | | | | |
| 2) | Enter your FT | P server port; | | | | | |
| | Port of most FTP server is 21; plz enter your FTP server corresponding port. | | | | | | |
| 3) | 3) Enter your FTP server password access. | | | | | | |
| | | pload photos to preset FTP account; if FTP is with wrong information P account will not be able to receive photos from camera. | | | | | |
| Se | nd To (4G mod | lel is able to send photos and videos to your emails/ FTP account) | | | | | |
| Ph | one | Enter recipients' phone numbers (1~4) | | | | | |

| Email | Enter recipients' email accounts(1~4) | | | | | | |
|--|--|--|--|--|--|--|--|
| Transfer mode: this funct | Transfer mode: this function allows camera to send photos or videos, or both | | | | | | |
| Photo | ON/ OFF | | | | | | |
| Video | ON/ OFF | | | | | | |
| SMTP/ FTP Pic Options | | | | | | | |
| | Original; Pictures sent via SMTP and FTP are in optional size as r (1920*1440), or Original (5M/ 8M/ 12M based on the Image Size you | | | | | | |
| Multishot Send: 1st/2nd | /3rd/4th/5th Pic; this function works with Multi-shot. | | | | | | |
| | i.e.: Multi-shot is set as 5P; and you choose 1 st Pic and 3 rd Pic in Multishot Send. Then the 1 st photo and 3 rd photo taken during 5 pics multi-shot will be sent out to your email(s) or FTP account. | | | | | | |
| Note: | | | | | | | |
| 1) camera will only send | photos to preset phone numbers via MMS; | | | | | | |
| 2) camera will only send | 2) camera will only send photos to preset email(s) via MMS if SMTP is not configured; | | | | | | |
| 3) camera will only send photos/ videos to preset email accounts via SMTP if SMTP is set. | | | | | | | |
| Max Num/Day | Max Num/Day | | | | | | |
| Default: unlimited; | | | | | | | |
| Optional: 1~99 | | | | | | | |
| i.e.: user chooses 50, then camera will only send (Photos/Videos) 50 times every day. Each time, camera will send to all entered emails/ phones/ FTP accounts. All the rest photos/ videos upon triggers will only be stored in SD card. | | | | | | | |

SMS Ctrl

1) By Trigger: (Suggest for AA battery power)

Camera will only be able to change & save setups remotely when camera is triggered to shoot photos/ videos.

2) All the Time: (Suggest using when Power adapter connected as this option will consume huge battery power.)

Camera 4G module stand-by all the time; so camera setups can be changed and saved whenever you sent the remote SMS setup commands.

Daily Report

1) OFF;

2) ON; Choose ON to enter to set up a time when you want camera to send you the Daily Report;

Contents contain in Daily Report: Device IMEI Number, CSQ (Signal Strength): 0~31, Camera ID, Temperature, Date & Time, Battery Left Volume, SD Card Info, Total Pics Taken by Cam, Send Times

SIM PIN

You can ignore description below if your SIM has been activated already.

(Phase "PIs input PIN-Code" will not pop up after signal search if your SIM is activated.)

- 1) Camera will check if inserted SIM card is activated during signal search in "Test" mode;
- 2) If SIM is not activated, "PIs input PIN-Code" will pop up on screen after signal search;
- 3) Then "SIM PIN" will turn to be configurable in "4G" page of Menu;
- 4) Enter PIN code in "SIM PIN"; camera will auto power off. Camera will activate SIM card automatically during signal search when you restart the camera after you enter the PIN code.

Note:

- 1) "Pls input PIN-Code" will pop up again if wrong PIN code is entered;
- 2) Pls re-try your PIN code as if you see "Pls input PIN-Code" after signal search;
- 3) SIM is normally limited to be activated 3 times; it'll be locked if PIN code entered are all wrong during these 3 times trial. So we suggest you to double confirm your PIN code before you try again.
- 4) Pls insert SIM card into your phone to unlock it by using its PUK code after 3 times trial of activation based on steps above.

GPS

ON/ OFF

| Cam | PIR | 4G | Other | Cam | PIR | 4G | Other |
|--------------|--|------|-----------|----------|-----|-----|-------|
| Language | | | En | SD Cycle | | | ON |
| Date/Time | | Au | Password | | OFF | | |
| Stamp | | ON | Reset | | | | |
| Battery type | | ALK | FW Update | | | | |
| Frequency | | 50Hz | About | | | | |
| MENU Exit | | Set | MENU E | xit | OK | Set | |
| | and the second | OK | | | xit | OK | Set |

| Other | |
|----------|---------|
| Language | English |

| Date/Time | Month : date : year; hour : minute : second Note: PIs adjust camera date/time to ensure some functions work as expected. |
|--------------|---|
| Stamp | Imprints of programmed camera ID, moon phase, temperature, date, and time on photo |
| Battery Type | Alkaline/ NI-MH Choose correct battery type of using batteries in camera makes camera perform better. |
| Frequency | 50HZ, 60HZ; improper setting may cause camera screen flicker |
| SD Cycle | Select "ON", press "OK", camera will continue to record photos/videos by deleting earliest photos or video clips. |
| Password | Select "ON", press "OK", to enable password protection for your camera; support totally 6 digits/ alphabets long password access. |
| Reset | Select "Yes" to reset camera back to factory default settings. |
| FW Update | With update firmware in the SD card, you can enter this menu to update camera firmware. Without firmware in |
| About | Firmware version in camera (Version: / IMEI: / MCU:) |

5. Trouble Shooting

5.1 Photos Do Not Capture Subject of Interest

1. Check the "SENOR LEVEL" (PIR SENSITIVITY) parameter setting. For warm environmental conditions, set the Senor Level to "HIGH" and for cold weather use, set the Sensor Level "LOW".

2. Try to set your camera up in an area where no heat resources are in the camera's field of view.

3. In some cases, set the camera near water will make camera take images with no subjects in them. Try to aim the camera over ground.

4. Try to set camera on stable and immovable objects i.e. large trees

5. At night, motion detector may detect beyond range of the IR illumination. Reduce distance setting by sensor sensitivity.

- 6. Rising sun or sunset can trigger sensor. Camera must be reoriented.
- 7.If person/animal moves quickly, it may move out of camera's field of view before photo is taken. Move camera further back or redirect camera.
- 8. Try to avoid setting the camera up on some small trees that are prone to being moved by strong winds.
- 9. Remove any limbs which are right in front of the camera lens.

5.2 Camera Stops Taking Images or Won't Take Images

- 1. Please make sure that the SD card is not full. If the card is full, camera will stop taking images. Or user can turn on cycle recording to avoid such problem
- 2. Check batteries to make sure that alkaline or NiMH AA left power is enough for camera to work
- 3. Make sure that the camera power switch is in the "ON" position and not in the "OFF" or "TEST" modes.
- 4. When 4G function is on, there will be around 1-minute interval for camera to send out photo before camera shooting the next photo. Turn off the GPRS, camera can shoot photos continuously.
- 5. Please format the SD card with camera before using or when camera stops taking images.

5.3 Night Vision Flash Range Doesn't Meet Expectation

1. Please check to make sure that batteries are fully charges or left power is enough

- 2. "MAX RANGE" offers better IR flash range. Given IR flash range values are based on Max Range setting so please adjust Night Mode to Max Range for better night vision flash range.
- 3. High-quality 1.5V NiMH rechargeable AA batteries cam also offer much better IR flash range; alkaline batteries cannot deliver enough amperage to power the illuminator consistently at night.
- 4. To ensure accuracy and quality of night time image, please mount camera to dark environment without ang obvious light sources.
- 5. A certain surrounding (like trees, wall, ground etc) within flash range can get you better night time images; please do not aim camera to total open field where there is nothing within IR flash range to reflect flash back; it's like shinning a flashlight into sky in night, you just can't see anything; same does camera.

| Image Sensor | 5 Mega Pixels Color CMOS |
|------------------|---|
| Effective Pixels | 2560x1920 |
| Day/Night Mode | Yes |
| IR range | 20m |
| IR Setting | Top: 27 LED, Foot: 30 LED |
| Memory | SD Card (4GB – 32GB) |
| Operating keys | 7 |
| Lens | F=3.0; FOV=52°/100°; Auto IR-Cut-Remove (at night) |
| PIR Angle | 65°/100° |
| LCD Screen | 2" TFT, RGB, 262k |
| PIR distance | 20m (65feet) |
| Picture size | 5MP/8MP/12MP = 2560x1920/3264x2448/4032x3024 |
| Picture Format | JPEG |
| Video resolution | FHD (1920x1080), HD (1280x720), WVGA(848x480) |
| Video Format | AVI |
| Video Length | 05-10 sec. programmable for wireless transmission; |
| | 05-59 sec. programmable for no wireless transmission; |

6. Specification

| Picture size for wireless transmission | 640x480/ 1920x1440/ 5MP/ 8MP or 12MP(depend on the Image Size setting) |
|--|---|
| Shooting Numbers | 1-5 |
| Trigger Time | 0.4s |
| Trigger Interval | 4s-7s |
| Camera + Video | Yes |
| Device Serial No. | Yes |
| Time Lapse | Yes |
| SD Card cycle | ON/OFF |
| Operation Power | Battery: 9V; DC: 12V |
| Battery Type | 12AA |
| External DC | 12V |
| Stand-by Current | 0.135mA |
| Stand-by Time | 5~8 months (6×AA~12×AA) |
| Auto Power Off | In Test mode, camera will automatically power off in 3 mins if there is no keypad touching. |
| Wireless Module | LTE Cat.4 module; 2G & 3G networks are also supported in some countries. |
| Interface | USB/SD Card/DC Port |
| Mounting | Strap; Tripod |
| Operating Temperature | -25°C to 60°C |
| Storage temperature | -30°C to 70°C |
| Operation Humidity | 5%-90% |
| Waterproof spec | IP66 |
| Dimensions | 148.25*117.37*78.25 mm |
| Weight | 367 g |
| Certification | CE FCC RoHs |

7. Warranty

With great pride and full confidence in our products, we always keep our words which are given to our customers as specified warranty terms and services below. Based on a strict QC system, we initially offer all our customers one-year long time limited warranty, come along with selectable chargeable renewal policy of warranty as one, two, three, or four years.

Our products are warranted against defects in materials and workmanship for a period of one year from the date of original purchase. If a defect exists, we will, at our option and to extent permitted by law will (1) repair the product at no charge using new or refurbished parts; (2) exchange the product with a functionally equivalent product that is new or refurbished. Provided the product is returned freight charge paid.

This warranty excludes damage resulting from abuse, accident, modifications or other causes that are not defects in materials and workmanship, or by someone other than our authorized technicians. This warranty only covers failures due to defects in materials or workmanship under normal usage.

To obtain warranty service, please contact us to determine the nature of problem before return the product under this warranty (with a written description of the problem and print samples) for repairing or exchanging.